

WATERSPORTS ACCESSORIES for Easy Shot Ultra Mini Digital Video Camera

What is in the package?



Note:



Easy Shot Clip Digital Video Camera
(not included in the package)

Use Easy Shot Clip in waterproof housing.




Easy Shot Clip Digital Video Camera
(not included)

Place Easy Shot Clip Digital Video Camera (not included) into the waterproof housing. Please ensure the lens of the camera is facing the same direction as the lens of the waterproof housing. Close the cap of the waterproof housing before use.

Use Easy Shot Clip and waterproof housing with included accessories.


A. Wrist Strap




Attach wrist strap to the waterproof housing and adjust the strap to fit your wrist to ensure you won't lose the camera during your outdoor activity.

B. 360° Rotating Bracket for Diving & Ski Mask

This bracket enables you to attach the waterproof housing to the strap of a diving or ski mask with its hairclip style clamp for hands free video underwater or on the slopes.



Put the waterproof housing on the diving/ski mask bracket and close the latch. Adjust the camera angle by turning the housing horizontally or the bracket vertically. Open the side clip and attach to masks or goggles.



Clip on diving/ski mask or swim goggles

Limited warranty.

The manufacturer warrants the products for a period of 90 days from the date of purchase to be free from defects in material and workmanship. The manufacturer, at its option, will repair or replace or have it repaired or replaced, at a location selected by the manufacturer, each product which is proven to the satisfaction of the manufacturer to be defective in material or workmanship. This warranty shall be limited to the defects which were not caused by misuse, abuse, improper handling, tampering or attempts to repair by the owner or any authorized repair service or repair man. This warranty is limited solely to the above and applies only for the period set forth. The manufacturer will not be liable for any loss or damage incidental or consequential of any kind, whether based on warranty, contract or negligence arising in connection with the sale, use or repair of the products. The manufacturer's maximum liability shall not in any case exceed the sale price. This warranty is for the benefit of the original purchaser only. This warranty gives you specific legal rights and may vary from jurisdiction to jurisdiction. The manufacturer makes no representations or warranties with regard to the contents of the User's Guide and/or Quick Start Guide. Non-manufacturer branded equipment distributed in this package are sold "as is" and without warranty of any kind from the manufacturer, including any implied warranty regarding merchantability, fitness for a particular purpose, and non-infringement of third party rights, and all such warranties are disclaimed. The sole warranty, if any, for non-manufacturer branded items, if any, is given by the producer thereof.

Get help.

Send email to customersupport@concordkeystone.com for any questions relating to diving/skiing accessories for Easy Shot Clip Ultra Mini Digital Video Camera.

© 2010 Concord Keystone Trading, LLC. All rights reserved. Easy Shot Clip is a trademark of Urcovest, LLC in the U.S. and/or other countries. All other product and company names mentioned herein are either registered trademarks or trademark of their respective owners.

Model # DV2WDIVACC

Accesorios WATERSPORTS para la cámara digital de video Easy Shot Clip

What is in the package?



Note:



Cámara digital de video Easy Shot Clip ultra pequeña
(no incluida en este paquete)

Utilice la cámara Easy Shot Clip con la cubierta impermeable



Cámara digital de video Easy Shot Clip
(no incluida)

Coloque la cámara Easy Shot Clip dentro de la cubierta impermeable. Por favor, asegúrese de que el lente de la cámara esté en la misma dirección del lente de la cubierta. Cierre la tapa de la cubierta impermeable antes de usar.

Uso de la cámara Easy Shot Clip y la cubierta impermeable con los accesorios.


A. Cinta de muñeca ajustable



Sujete la banda para la muñeca a la cubierta impermeable y ajuste la banda para que se ajuste a su muñeca y así asegúrese que no perderá la cámara durante su actividad al aire libre.

B. Soporte rotatorio de 360° para mascarás de buceo y esquí

Este soporte le permite sujetar la cubierta impermeable a la banda de una mascarás de buceo o esquí con su pinza estilo horquilla para filmar videos manos libres bajo agua o esquiando.



Coloque la cubierta impermeable en el soporte de la mascarás de buceo o esquí y cierre el pestillo. Ajuste el ángulo de la cámara girando la cubierta horizontalmente o el soporte verticalmente. Abra el clip lateral y engánchelo a mascarás o anteojos de protección.



Montar en mascarás de buceo/esquiar o de natación

Garantía limitada.

El fabricante garantiza que durante un lapso de 90 días, a partir de la fecha de compra, los productos estarán libres de fallas en lo que respecta a materiales y mano de obra. El fabricante, a su opción, podrá reparar o reemplazar, o hacer que se repare o reemplace, en un sitio que seleccione el fabricante, cada uno de los productos cuya falla relacionada con los materiales o la mano de obra se demuestre a satisfacción del fabricante. Esta garantía quedará limitada a los productos que tengan fallas no relacionadas con el uso indebido, abuso, manejo inadecuado, o que se generen porque el dueño o algún servicio de o técnico de reparación autorizado traten de manipular indebidamente la producto. Esta garantía se limita únicamente a lo anterior y aplicará sólo durante el período indicado. El fabricante no será responsable de ninguna pérdida o daño incidental o indirecto de ningún tipo, ya sea que este basado en la garantía, un contrato, o negligencia que surja en conexión con la venta, uso, o reparación de los productos. La máxima responsabilidad del fabricante en ningún caso podrá sobrepasar el precio de venta. Esta garantía se otorga únicamente en beneficio del comprador original. Esta garantía otorga determinados derechos legales y puede variar entre las diversas jurisdicciones. El fabricante no hace ninguna afirmación ni da garantía alguna con respecto al contenido de la Guía del Usuario y/o la Guía de Inicio Rápido. Los dispositivos y el software incluidos con la paquete cuya marca no es del fabricante se venden "tal como están" y sin garantía de ningún tipo de parte del fabricante de los productos, incluyendo cualquier garantía implícita sobre la posibilidad de mercadeo, o idoneidad para un fin en particular, o la no-violación de derechos de terceros, siendo que en el presente se desconocen todas tales garantías. La única garantía respecto a los dispositivos cuya marca no es del fabricante, es la que brinda el productor del mismo, si la hubiese.

Para conseguir ayuda.

Si tiene alguna pregunta sobre la cámara de video digital Easy Shot Clip, envíe un correo electrónico a customersupport@concordkeystone.com.

© 2010 Concord Keystone Trading, LLC. All rights reserved. Easy Shot Clip is a trademark of Urcovest, LLC in the U.S. and/or other countries. All other product and company names mentioned herein are either registered trademarks or trademark of their respective owners.

Modelo # DV2WDIVACC